



### **ECO FRIENDLY PLAYER**

Digital On Hold Player is ROHS Compliant

### **LARGE EASY TO SEE BUTTONS**

Digital On Hold Player has large easy to see and feel buttons for ease of operation. The LED indicators are super bright to give a clear indication of mode and function. The play LED flashes bright blue during normal operation.

### **SAFETY WARNING**

Super Bright LED's are used for indication only and we do not recommend looking into these for extended periods of time (Max recommended 2-3 secs at an indirect angle) Keep distance to min 50cm. No user serviceable parts are inside this device. If the device fails contact your supplier for a replacement.



**Absolute Phone & Data**  
**Sell a Range of Products**  
**Including**

- On Hold Players**
- Telephone Systems**
- Headsets**
- Cordless Phones**
- PA Systems**
- Call Software**
- VoIP Phones**
- Payphones**

### **Service Areas**

- Brisbane 07 3849 6291**
- Gold Coast 07 5592 1122**
- Ipswich 07 3849 6291**
- Beaudesert 07 5546 9576**

[www.absolutephoneanddata.com.au](http://www.absolutephoneanddata.com.au)

All components of this device supplied under



# **KAZRO DIGITAL ON HOLD PLAYER**



## **USER GUIDE**

**MODEL: TRIPLE 888**

SUPPLIED BY **ABSOLUTE PHONE & DATA**



USB connection is labeled USB and SD/MMC connection is labeled SDC



Red indicates POWER ON  
Blue Flashing Indicates PLAY

## Installation and Operation Guide

### Important Information

This is a self installation guide, if you do not feel confident in proceeding with installation please call technical support.

If unit fails please call technical support

07 5546 9576

Remove On Hold Digital Player from packaging (A). Connect power supply to socket labeled Power (B). Connect either the USB key or your SD card as shown (C & D). Turn on the power amplifier (E) then select either Multi track RED or Single track GREEN for your play mode (F). Connect the audio out to your phone system via the output (L-Out) (G). Adjust the volume as necessary (H) until the desired volume is attained.

### Multi Track Play Function

The cycle indicator displays RED. This mode is default and is multi track continuous play where all files on the USB key will cycle indefinitely.

### Single Track Play

Press the cycle button to display GREEN. This function will then play only the currently selected file even if there are more than one file stored on the USB or SD device. The file will cycle indefinitely.

### Skip To Track

When using the single track function you can select up or down by the arrows (F) to select the desired track to play. Once you have found the correct track the digital player will continuously play the track.

### Volume Adjustment

To adjust volume on digital player simply press V+ or V- until desired volume level is reached (F). All volume adjustment is digital, less wear and tear on the unit leading to durability of product.

### Audio Connection

To connect the output on the digital player you have several choices. The most commonly used is the L-OUT being left audio for LIU connection.

There are two other outputs which in cases can be used if you have a different connection type. These are the R-OUT and the LINE OUT (Line out is a stereo output generally used when connecting to a device requiring stereo output).



Factory default is RED—Play ALL FILES



Note:- For best result use the L-OUT



## TECHNICAL INFORMATION

POWER	12V DC	500MA
POWER AMPLIFIER	8 WATT	
IMPEDANCE	8 OHM 3.5 MM MONO	3.5MM STEREO AVAILABLE
USB / SD CARD	USB INCLUDED	SD CARD OPTIONAL